



HOME OWNER GUIDE BOOKLET

1746 LAKEWOOD ROAD
TOMS RIVER, NJ 08755

PHONE: 732-286-6300
FAX: 732-341-1465

HOME OWNER GUIDE BOOKLET

TYPES OF SAFETY COVERS

1. Advanced Mesh Safety Cover.
2. Solid Safety Cover With Window.
3. Solid Safety Cover With Removable Filter.

ACCESSORIES

1. Brass anchors, wood and concrete.
2. Brass Flanges.
3. Pavers Stakes.
4. Padding.
5. Coping Protectors.

MAINTAINING YOUR COVER

1. Concrete and wood Anchors.
 - A. Clean and lube anchors every OPENING AND CLOSING.
 - B. Clean and maintain cover frequently for leaves, garbage, etc..
 - C. Clean cover before storage.
 - D. Inspect cover for damage.

STORING YOUR COVER

2. Mesh and Solid covers.
 - A. Remove all leaves and debris from cover.
 - B. Hose cover off as needed. Soap and water.
 - C. Check cover for damage. If your cover has damage have it repaired ASAP.
 - D. Fold cover and store in mesh bag included with your order.
 - E. Hang bag off the ground to avoid mice and rodents.
 - F. Keep cover away from chemicals and heat.

CLOSING YOUR POOL IN THE FALL

The cover should be checked for damage that may have occurred during storage. Never raise the deck anchors prior to reinstalling, as damage may occur by dragging the cover over raised anchors. Keep

anchors flush until the cover is positioned correctly over the pool. When moving or handling the cover, never grab the paneled material, always move the cover by using the reinforced webbing and straps. The water level in the pool must be between 15" inches and 18" inches below the cover at all times, or the warranty will be voided.

HOW TO USE THE INSTALLATION TOOL TO INSTALL THE COVER

Using the allen wrench, raise the threaded portion of the brass anchor approximately 1/4". Slip the installation tool through the round end of the stainless steel spring. Stand facing the pool and place the installation tool over the brass anchor with the notched end facing the pool. Using your body for leverage, pull the top of the installation tool away from the pool, seating the spring on the brass anchor. You may want to gently step on the spring as it slides down the installation tool. Twist the installation tool to cause the notched area to line up with the back of the spring.

TIGHTENING STRAPS

In the event the springs are not compressed 50% for mesh covers and between 60% to 75% for solid covers, or the straps become loose, the straps should be tightened. Loose straps can cause premature cover wear. Remove the spring from the anchor with the installation tool. Using the strap and buckle, adjust the length of the strap by 2 inch increments and reinstall the spring on the anchor, using the installation tool until the spring is compressed 50% for mesh covers and 60% to 75% for solid covers and the straps are snug.

LEAVES COLLECTING ON COVER

Leaves collecting on the cover is a normal circumstance. Simply allow them to dry and blow off. Should you find that the leaves tend to collect on the cover, ensure that the straps are taut across the pool to allow the leaves to blow away.

WATER NOT COLLECTING NEAR THE PANEL

In the event that the water seems to collect in an area of the cover that does not have a window mesh drain panel, the straps of the cover can be adjusted to direct the water towards the drain for proper drainage.

Step 1: Loosen the four straps that border the window mesh panel.

Step 2: Tighten the straps that are outside or surrounding the accumulation of water.

Step 3: The water might need assistance to begin moving towards the panel. Try to temporarily depress the cover near the panel to help the flow of water towards it. In some situations you may need to add some weight to that area of the cover.

Step 4: Wait 2 to 3 days to allow the cover to “tighten” then flood the cover with a garden hose to check that the cover drains properly on its own.

Step 5: Repeat above steps as needed.